

MOTION 1 SOFTWARE USER GUIDE

CONTENTS

1. SOFTWARE INSTALLATION 2

1.1	MasterPlus+ DOWNLOAD	2
1.2	ONE-STOP INSTALLATION FROM MasterPlus+	2
1.3	QUICK LAUNCH WITH D-BOX MOTION CORE	3

2. D-BOX CONNECT ACCOUNT SETUP & HAPTIC MODE INSTRUCTIONS 4

2.1	SYSTEM CHECK	4
2.2	CREATE A D-BOX CONNECT ACCOUNT & REDEEM YOUR SUBSCRIPTION	5
2.3	ACTIVATE YOUR DEVICE ON D-BOX HaptiSync APP	6
2.4	INSTRUCTIONAL VIDEOS & ACCESS FOR 4 HAPTIC MODES	8
2.5	FINISHED & ONLINE RESOURCE HYPERLINK	9
2.6	HAPTIC MODES INSTRUCTIONS	10
2.6.1	D-BOX CODED GAMING	11
2.6.2	D-BOX CODED VIDEO	12
2.6.3	ADAPTIVE GAMING	13
2.6.4	ADAPTIVE AUDIO	14

3. MOTION 1 CONTROL FUNCTIONS IN MasterPlus+ 15

3.1	MOTION 1 SETTINGS	16
3.1.1	MODE SWITCHING	16
3.1.2	STOP MOTION	16
3.1.3	ADJUST MOTION / VIBRATION INTENSITY	16
3.2	LIGHTING	17
3.3	HELP CENTER	17

1 SOFTWARE INSTALLATION

1.1 MasterPlus+ DOWNLOAD



Please download and install the latest version from masterplus.coolermaster.com

As the installation process includes D-BOX Motion Core software, you will be ready for all software features once installation is complete.

1.2 ONE-STOP INSTALLATION FROM MasterPlus+

Plug in the power cord & USB cable, and turn on the power before launching MasterPlus+.


The Power button is between the USB & Power plug.

POWER CORD


POWER BUTTON

USB CABLE

Click on the **Install** button in the pop-up notification to start, there will be several installations to be completed before the next step.



Please ensure you've completed all the installation steps, then click OK to launch MasterPlus+. Computer restart is recommended if on Windows 10 or an earlier version.




1.3 QUICK LAUNCH WITH D-BOX MOTION CORE


You can also download and install D-BOX Motion Core directly from <https://www.d-box.com/en/software-downloads> to have a quick launch for your Motion 1.

You will skip the built-in instructions and customized functions in **MasterPlus+**.


STATUS CHECK



MOTION 1 FIRMWARE

 Installed and up to date

D-BOX DRIVER INSTALLATION

 Installed and up to date

1: LAUNCHING

RESTART MASTERPLUS

WATCH SETUP VIDEO

CLICK HERE

2.1 SYSTEM CHECK

Software will auto-check driver & firmware status. If the **RESTART MASTERPLUS+** button shows up in **orange**, you should click to restart MasterPlus+ for an update.

2 D-BOX CONNECT ACCOUNT SETUP & HAPTIC MODE INSTRUCTIONS

2.2 CREATE A D-BOX CONNECT ACCOUNT & REDEEM YOUR SUBSCRIPTION

Your **D-BOX Connect Account** is mandatory to install and update haptic codes for D-BOX Coded Games and D-BOX Coded Movies.


Click on **Create D-BOX Connect Account** to access the website (<https://connect.d-box.com>) and follow the onscreen instructions.

If you have a promo code, you can redeem your subscription in your account.
Motion 1 comes with a complimentary life-time subscription.

Web Instruction:

(<https://support.d-box.com/en/knowledge/how-to-create-your-d-box-connect-account>)

Promo code will be on the sticker with your product.



Please create a **D-BOX CONNECT ACCOUNT**. For the best immersive experience, you will need a D-BOX HaptiSync subscription.
If you have a promo code, you can redeem your free one-year subscription in your account.*

Please return to this screen after your **D-BOX CONNECT ACCOUNT** is created.

2: ACCOUNT

BACK

CREATE D-BOX ACCOUNT



I ALREADY HAVE AN ACCOUNT

CLICK HERE

2.3 ACTIVATE YOUR DEVICE ON D-BOX HaptiSync APP



Open the D-BOX HaptiSync app. You will see your computer name and the message **Activation Required**, if not already activated. Click on your computer and follow the steps until you see the **Activation** confirmation.

You will need to confirm and re-login to your D-BOX Connect account.



After activating your account and purchasing your subscription, your subscription status will be updated and the content (movie haptic codes) will download to your computer automatically.


You will see a **Downloading content...** message under your computer name, and the download status will be real-time updated as a percentage.



Depending on your internet connection speed, it could take a few hours the first time to download haptic codes for the latest/famous 2500+ movies, series and more. (~20GB)

IMPORTANT: You have to complete the download to utilize the D-BOX Coded Video mode.

Web Instruction: (<https://support.d-box.com/en/knowledge/dbox-pc-activation-hsa>)




Watch the videos to understand:
How to get the most out of games with **D-BOX CODED GAMING** mode.
How to play any game with **D-BOX ADAPTIVE GAMING** mode.




2.4 INSTRUCTIONAL VIDEOS & ACCESS FOR 4 HAPTIC MODES

All four HaptiSync modes are detailed in corresponding **one-click instructional videos** to guide you through the initial setup. You can follow the onscreen instructions to watch them all, and click on the **D-BOX HaptiSync app** button to access and execute those setups, or review them in the **HELP CENTER** functional tab afterwards.



Watch the videos to understand:
How to get the most out of movies with **D-BOX CODED VIDEO** mode.
How to «Next Level» any content with D-BOX'S **ADAPTIVE AUDIO** mode.





MOTION 1

2.5 FINISHED & ONLINE RESOURCE HYPERLINK



Get Immersed! Your MOTION 1 has been setup and is fully activated.
You can find all help videos and software guides in the [HELP CENTER](#).

FEEL YOUR WORLD

COMPLETE

BACK

GO TO HELP CENTER

CLOSE


CLICK HERE

Initial setup completed, [GO TO HELP CENTER](#) if you want to review the instructional videos.


2.6 HAPTIC MODES INSTRUCTIONS

You can select/switch HaptiSync modes from the following apps:


a) MasterPlus+: Motion 1 Setting



b) D-BOX HaptiSync app



c) D-BOX Game Center



The HaptiSync mode will be synchronized in all apps.


IMPORTANT:

Before playing games/videos, please make sure that you are in the correct mode to ensure proper functioning.

2.6.1 D-BOX CODED GAMING

Premium haptic experiences for D-BOX coded games.
Use the Adaptive Gaming mode if your title is not in the list.


- Select the HaptiSync Mode **D-BOX Coded Gaming** in MasterPlus+
- Click on Advanced Settings to launch the **D-BOX Game Center**, where you can check the supported game list and select the game you want to play.
- Click on **Install** to install the haptic code of your game.
(This needs to be done the first time you want to play the game or when there is an update to the haptic code).



The screenshot shows the D-BOX Game Center window. The HaptiSync Mode is set to 'D-BOX Coded Gaming'. A dropdown menu is open, showing options: 'D-BOX Coded Gaming', 'D-BOX Coded Video', 'Adaptive Gaming (Beta)', and 'Adaptive Audio (Beta)'. Below the menu is a table of games. The 'ACTC' game is highlighted, and its 'Install' button is circled in orange. An orange arrow points to the 'Install' button with the text 'CLICK HERE'.

Name	Status	Startup	Installed	Available	Type	Comment
ACTC	Not Detected		Not Installed	1.1.5274	Racing	Up to 35 mm (1.5")
Aeolis Tournament	Not Detected		Not Installed	1.0.10993	Arcade	Up to 152 mm (6")
Aerofly FS2	Not Detected		Not Installed	2.1.10919	Flight	Up to 152 mm (6")
American Truck Sim	Not Detected		Not Installed	1.1.10941	Racing	Up to 152 mm (6")
ARCA Sim Racing	Not Detected		Not Installed	1.3.5341	Racing	Up to 35 mm (1.5")
Assassin's Creed Valhalla	Not Detected		Not Installed	1.2.11128	Adventure	Up to 152 mm (6")
Assetto Corsa	Not Detected		Not Installed	4.3.11124	Racing	Up to 152 mm (6")
Assetto Corsa Competizione	Not Detected		Not Installed	2.3.11124	Racing	Up to 152 mm (6")
Automobilista	Not Detected		Not Installed	1.0.9455	Racing	Up to 152 mm (6")
Automobilista 2	Not Detected		Not Installed	1.1.11084	Racing	Up to 152 mm (6")
BeamNG	Not Detected		Not Installed	1.0.10716	Racing	Up to 152 mm (6")
Bomber Crew	Not Detected		Not Installed	1.0.11005	Strategy	Up to 152 mm (6")
City Car Driving	Not Detected		Not Installed	1.0.11006	Racing	Up to 152 mm (6")
Crysis WARHEAD	Not Detected		Not Installed	1.2.5274	Shooter	Up to 35 mm (1.5")

- Follow the instructions in the pop-up window or click on **Special Instructions** for the pre-launch guide.
- Click on **Launch** to start your game and play!



The screenshot shows the D-BOX Game Center window. The HaptiSync Mode is set to 'D-BOX Coded Video'. The 'Forza Horizon 5' game is highlighted, and its 'Special Instructions' button is circled in orange.

Name	Status	Startup	Installed	Available	Type	Comment
Forza Horizon 5	Ready	Special Instructions	1.1.11111	1.1.11111	Racing	Up to 152 mm (6")
ACTC	Not Detected		Not Installed	1.1.5274	Racing	Up to 35 mm (1.5")

2.6.2 D-BOX CODED VIDEO

Premium haptic experiences for D-BOX coded movies, TV shows, using audio synchronization. Use the Adaptive Audio mode if your title is not listed in the haptic library.

MOTION 1

- a) Select the HaptiSync Mode **D-BOX Coded Video** in MasterPlus+
- b) Click on Advanced Settings to launch the **HaptiSync app**.
- c) Go to **D-BOX CODED VIDEO CONFIGURATION** section and select your main **Audio Source** (the source from which you are listening to).
- d) After you see a recent **Last updated** date to confirm haptic library download, your Motion 1 is ready. You can also open the **List of D-BOX Coded Titles** to validate if the movie you want to watch was natively coded by D-BOX.

D-BOX CODED VIDEO CONFIGURATION

Audio Source

OUT: Speakers (Realtek(R) Audio Codec with THX Spatial Audio)

Start your movie and wait for the audio synchronization to complete. Motion should start within a minute. You will see the movie title appear in the **"Now Playing"** section.

HAPTISYNC SUBSCRIPTION



Signed in as @d-box.com

✔ Subscription Active




Last Updated: 2023-05-04 15:56:40

2.6.3 ADAPTIVE GAMING

Haptic experiences using real-time events from game controller or keyboard.

- Select the HaptiSync Mode **Adaptive Gaming** in MasterPlus+
- Click on Advanced Settings to launch the **Adaptive Gaming Configurator** and turn ON the **Adaptive Gaming Enabled** switch.
- Select an integrated profile with specific IO input / game from the **Adaptive Profile Selector**, or create a unique profile for your favorite games.




d) Follow the built-in tutorials to help you understand how to create a profile.

e) **Start your game and play!**

2.6.4 ADAPTIVE AUDIO

Automated haptic experiences for any movie, music, TV show and games using audio processing.

- a) Select the HaptiSync Mode **Adaptive Audio** in MasterPlus+
- b) Click on Advanced Settings to launch the **HaptiSync app**.
- c) Go to **ADAPTIVE AUDIO CONFIGURATION** section and select your main **Audio Source** (the source from which you are listening to).




- d) Start your movie (or game), haptic feedback from sound should start quickly after the movie or game begins.

3 MOTION 1 CONTROL FUNCTIONS IN MASTERPLUS+

MOTION 1 SETTINGS LIGHTING HELP CENTER

Status **OK**



HAPTISYNC MODE SELECTION

- STOP MOTION
- D-BOX CODED GAMING
- D-BOX CODED VIDEO
- ADAPTIVE GAMING
- ADAPTIVE AUDIO

ADVANCED MODE SETTING

HAPTIC SETTINGS

Movement Intensity

LOW ————— HIGH

Vibration Intensity

LOW ————— HIGH

3.1 MOTION 1 SETTINGS


3.1.1 MODE SWITCHING

After you've finished the initial setup for all haptic modes, you can easily switch modes here. Click **ADVANCED MODE SETTINGS** if you want to do any detailed settings, such as install new game haptic code/select new Audio source, etc...


3.1.2 STOP MOTION

This switch allows you to freeze all motion and vibration for a short break or a no-haptic use case. It will automatically switch to OFF to enable motion and vibration when you are doing adjustment in 3.1.1 & 3.1.3.


a) STOP MOTION OFF (Default)




b) STOP MOTION ON (Motion freeze)



3.1.3 ADJUST MOTION / VIBRATION INTENSITY





3.2 LIGHTING

Adjust the ARGB lighting effects of the seat lightbox to your liking.

3.3 HELP CENTER

You can review all setup instructions & customer service resources here.

